



① Trim panels

Roll the paper out on a flat clean surface and trim the panels. Unless supplied in a 5 metre roll (16.4ft), each panel is printed to the height specified and is separated by a white line. Our logo header indicates the top of each panel. You will notice that every second panel is upside down. If the wallpaper is a mural, ensure you keep the order of panels correct as you will be installing from left to right from panel no. 1.

② Prepare wall surface and position

The wall or door should be flat, clean and sealed with a primer sealer or normal wall emulsion. Fill rough holes and flatten uneven spots. The first panel determines the overall appearance of the installation so it is important to proceed with accuracy. Start with the top left panel and use a plum line, ruler and pencil to position the first panel as accurately as possible along a straight edge.

③ Adhesive

Mix the paste following the instructions on the packet.

Tip! Use a good quality paste to avoid the paste yellowing over time. Paste should not be too sloppy. Using a paint roller or brush, evenly spread a fair amount of wallpaper paste on to the wall. Just paste enough of the wall for 1-2 panels at a time to avoid it drying off by the time you get to it. Keep applying as you go.

④ Wallpapering

Place the panel according to the left straight edge. Remove all air bubbles by stroking them from the centre outwards.

Tip! For bubble-less panels every time, try placing the wallpaper on to the glue roughly in position and smooth over quickly, then remove and reposition accurately into place. This wets the back of the paper and helps to discourage air bubbles.

Use a damp clean cloth to remove any bubbles or excess glue. Work from top to bottom and from the centre out.

Tip! You will obtain a perfect result when papering at a room temperature of 18-20 degrees Celsius (68 degrees Fahrenheit). Avoid draughts as the drying period should be quite long to ensure edges do not separate.

⑤ Finishing

Finally trim any excess by using a straight edge and a sharp cutting knife. Remove excess adhesive with a damp clean cloth.

Due to rigorous quality control, we endeavour to dispatch faultless products. Slight colour deviations are technically unavoidable, however should you have any reason for complaint, please let us know before installing the wallpaper as we cannot assume liability for the cost of replacing in this case.

If you need any assistance, please contact

info@digitile.co.uk

www.digitile.co.uk